

**BLAZER**  **RANGE**™  
BLASTABLE LASER MASK

&

**BLAZER**  **RANGE**™  
BLASTABLE LASER MASK

XL

# USER'S GUIDE

## BLAZER RANGE

### INSTRUCTIONS

1. Unroll and cut to desired size.  
*If using Blazer Orange XL, remove slip sheet.*
2. Apply the laser mask to the side of the substrate that is to be first lasered and then blasted.
3. Squeegee out the air bubbles and wrinkles.
4. Remove the polyester carrier by flicking one edge of the carrier to loosen and then peel.
5. Laser through the film to create your sandblastable mask.
6. Sandcarve to desired depth up to 1/16 inch\*. Color-fill or finish as desired.
7. For removal of the film, simply peel or soak in water.

*\*Maximum depth can vary depending on the substrate used. For a deeper etch, try one of IKONICS Imaging's other quality films.*

P280 - Wear protective gloves/protective clothing/eye protection/face protection.  
P333+P313 - If skin irritation or rash occurs: Get medical advice/attention  
P305+P351+P338 - IF IN EYES: Rinse continuously with water for several minutes.  
Remove contact lenses, if present and easy to do. Continue rinsing.  
P501 - Dispose of content and/or container in accordance with local regional, national and/or international regulations.



 **IKONICS IMAGING**®

www.ikonicsimaging.com  
(800) 643-1037